

A Brief Note on Setup and Configuration of NI Vision

Author: Bob Sherbert

Keywords: NI, LabVIEW, NI Vision, USB Webcam

Setting Up the Software Tools

To use the NI Vision extensions and the USB camera module you will need to install a few pieces of software.

1. LabView 7.1 or Higher
2. NI Vision [Development Module](#)
3. NI-IMAQ for [USB Cameras](#)

Examples on Usage

NI provides a number of useful examples to demonstrate the functionality of the USB camera module. These display the setup of the module and its usage. Once you have installed the Vision and USB extension modules you will be able to find them at: `LABVIEWInstallDIR/examples/IMAQ/imaqUSBexamples.llb`

The author can be reached by [email](#)